

How to Correctly Determine Dust Scrubber Air Quantity

**Dust Division
Pittsburgh Safety and Health Technology Center**


Mark Schultz, P.E.
Senior Engineer



Purpose

Establish uniformity in performing pitot tube traverse measurements to correctly determine the scrubber flow rate.

Importance of Accurate Scrubber Air Readings



- Properly verify if plan scrubber quantity is correct
- Determine suitability of face ventilating air current for particular system of mining being used
- Permits ongoing assessment of scrubber performance

Equipment Requirements

- Pitot Tube of Proper Length
 - Good Condition
 - All ports open
 - Tip of nose free from nicks and burrs
- Magnehelic Gauge w/ Hoses
 - Calibrated
 - Oriented in Proper Position
- Tape Measure
 - Preferably in feet

Pitot Tube

- Device measures
 - Static Pressure
 - Total Pressure
- Difference between Static and Total Pressure is called **Velocity Pressure**
- **Velocity Pressure** is used to determine **Air Velocity**

Pitot Tube

- Rugged
- Does not need to be calibrated
- Very accurate for velocities above 800 fpm

You Won't Measure This (176,000 fpm)



Air Velocity Measurements Using the Pitot Tube

Pitot Tube used to measure air velocities in high velocity areas. (>2000 fpm)

1. Vane anemometers can be damaged in high velocities
2. Pitot Tube is more accurate at higher velocities

Velocity, fpm	% Error (\pm)
4000	0.25
3000	0.3
2000	1.0
1000	4.0
800	6.0
600	15.0

Pitot Tubes Used in Coal Mines

1. Main Mine Fans
2. Auxiliary Fans
3. Ventilation Tubing
4. Scrubbers

Converting Velocity Pressures to Velocities (fpm)

$$\text{Velocity} = 4005 \sqrt{V_p}$$

Velocity Pressure Conversion Table

Velocity Pressure Conversion

VP	V	VP	V	VP	V	VP	V	VP	V	VP	V
0.01	401	0.51	2860	1.01	4025	1.51	4921	2.01	5678	2.60	6458
0.02	566	0.52	2888	1.02	4045	1.52	4938	2.02	5692	2.70	6581
0.03	694	0.53	2916	1.03	4065	1.53	4954	2.03	5706	2.80	6702
0.04	801	0.54	2943	1.04	4084	1.54	4970	2.04	5720	2.90	6820
0.05	896	0.55	2970	1.05	4104	1.55	4986	2.05	5734	3.00	6937
0.06	981	0.56	2997	1.06	4123	1.56	5002	2.06	5748	3.10	7052
0.07	1060	0.57	3024	1.07	4143	1.57	5018	2.07	5762	3.20	7164
0.08	1133	0.58	3050	1.08	4162	1.58	5034	2.08	5776	3.30	7275
0.09	1202	0.59	3076	1.09	4181	1.59	5050	2.09	5790	3.40	7385
0.10	1266	0.60	3102	1.10	4200	1.60	5066	2.10	5804	3.50	7493
0.11	1328	0.61	3128	1.11	4220	1.61	5082	2.11	5818	3.60	7599
0.12	1387	0.62	3154	1.12	4238	1.62	5098	2.12	5831	3.70	7704
0.13	1444	0.63	3179	1.13	4257	1.63	5113	2.13	5845	3.80	7807
0.14	1499	0.64	3204	1.14	4276	1.64	5129	2.14	5859	3.90	7909
0.15	1551	0.65	3229	1.15	4295	1.65	5145	2.15	5872	4.00	8010
0.16	1602	0.66	3254	1.16	4314	1.66	5160	2.16	5886	4.10	8110
0.17	1651	0.67	3278	1.17	4332	1.67	5176	2.17	5900	4.20	8208
0.18	1699	0.68	3303	1.18	4351	1.68	5191	2.18	5913	4.30	8305
0.19	1746	0.69	3327	1.19	4369	1.69	5207	2.19	5927	4.40	8401
0.20	1791	0.70	3351	1.20	4387	1.70	5222	2.20	5940	4.50	8496
0.21	1835	0.71	3375	1.21	4406	1.71	5237	2.21	5954	4.60	8590
0.22	1879	0.72	3398	1.22	4424	1.72	5253	2.22	5967	4.70	8683
0.23	1921	0.73	3422	1.23	4442	1.73	5268	2.23	5981	4.80	8775
0.24	1962	0.74	3445	1.24	4460	1.74	5283	2.24	5994	4.90	8865
0.25	2003	0.75	3468	1.25	4478	1.75	5298	2.25	6007	5.00	8955
0.26	2042	0.76	3491	1.26	4496	1.76	5313	2.26	6021	5.50	9393
0.27	2081	0.77	3514	1.27	4513	1.77	5328	2.27	6034	6.00	9810
0.28	2119	0.78	3537	1.28	4531	1.78	5343	2.28	6047	6.50	10211
0.29	2157	0.79	3560	1.29	4549	1.79	5358	2.29	6061	7.00	10596
0.30	2194	0.80	3582	1.30	4566	1.80	5373	2.30	6074	7.50	10968
0.31	2230	0.81	3605	1.31	4584	1.81	5388	2.31	6087	8.00	11328
0.32	2266	0.82	3627	1.32	4601	1.82	5403	2.32	6100	8.50	11676
0.33	2301	0.83	3649	1.33	4619	1.83	5418	2.33	6113	9.00	12015
0.34	2335	0.84	3671	1.34	4636	1.84	5433	2.34	6126	9.50	12344
0.35	2369	0.85	3692	1.35	4653	1.85	5447	2.35	6140	10.00	12665
0.36	2403	0.86	3714	1.36	4671	1.86	5462	2.36	6153	10.50	12978
0.37	2436	0.87	3736	1.37	4688	1.87	5477	2.37	6166	11.00	13283
0.38	2469	0.88	3757	1.38	4705	1.88	5491	2.38	6179	11.50	13582
0.39	2501	0.89	3778	1.39	4722	1.89	5506	2.39	6192	12.00	13874
0.40	2533	0.90	3799	1.40	4739	1.90	5521	2.40	6205	12.50	14160
0.41	2564	0.91	3821	1.41	4756	1.91	5535	2.41	6217	13.00	14440
0.42	2596	0.92	3841	1.42	4773	1.92	5549	2.42	6230	13.50	14715
0.43	2626	0.93	3862	1.43	4789	1.93	5564	2.43	6243	14.00	14985
0.44	2657	0.94	3883	1.44	4806	1.94	5578	2.44	6256	14.50	15251
0.45	2687	0.95	3904	1.45	4823	1.95	5593	2.45	6269	15.00	15511
0.46	2716	0.96	3924	1.46	4839	1.96	5607	2.46	6282	15.50	15768
0.47	2746	0.97	3944	1.47	4856	1.97	5621	2.47	6294	16.00	16020
0.48	2775	0.98	3965	1.48	4872	1.98	5636	2.48	6307	16.50	16268
0.49	2804	0.99	3985	1.49	4889	1.99	5650	2.49	6320	17.00	16513
0.50	2832	1.00	4005	1.50	4905	2.00	5664	2.50	6332	17.50	16754

V = 4005 X √ VP

V = Velocity in fpm

VP = Velocity Pressure "WG

Why Not Use a Vane Anemometer?

- According to the ACGIH Industrial Ventilation Recommended Practice
 - This instrument is accurate to determine air flow through large supply and exhaust openings
 - The cross-sectional area of the instrument should not exceed 5% of the measured area
 - Standard 4" anemometer is unsuited for measurements in ducts below 20" diameter
 - Generally, useful range is below 3,000 fpm
 - Pitot tube has less error at higher velocities!

Ventilating Pressures

STATIC PRESSURE - The pressure in the system that tends to burst (positive pressure) or collapse (negative pressure) the walls of the system.

* VELOCITY PRESSURE - The pressure required to accelerate air from zero velocity to the velocity of the system at that particular point. It is proportional to the kinetic energy of the system.

TOTAL PRESSURE - The sum of the static pressure and the velocity pressure. Air will always flow from a region of lower Total Pressure to a region of higher Total Pressure.

Velocity Pressure Readings

- Get CM in good location
 - Air velocity readings can be taken at ports (low coal)
 - Inlets and exhaust of scrubber unobstructed
 - Raise cutterhead
- Clean screen and duct work
- Locate scrubber test ports
 - Loosen screws


Velocity Pressure Readings

- Obtain the duct cross-sectional area at location of test ports:
 - Measure depth and width $\text{Area} = \text{depth} \times \text{width}$
 - Measured location is in by test port location
 - Due to Pitot tube measurement ports
- Determine how many readings per test port to take
 - At least 14 readings for full Pitot traverse

Depth of Traverse Readings

- Decide how many readings to take per test port
 - Determine how many quadrants will be sampled
- Determine the depth of each quadrant
 - Depth / Number of readings
 - Depth is 16 inches, 4 readings per port
 - $16/4 = 4$ inches depth per quadrant
- Determine first traverse depth
 - First depth is $\frac{1}{2}$ of a quadrant depth
 - $4 \text{ inches} / 2 = 2 \text{ inches}$
 - First reading is at 2 inches
 - Keep adding quadrant depth to previous reading for additional readings
 - $2 \text{ inches} + 4 \text{ inches} = 6 \text{ inches}$ 2nd reading depth
 - $6 \text{ inches} + 4 \text{ inches} = 10 \text{ inches}$ 3rd reading depth
 - $10 \text{ inches} + 4 \text{ inches} = 14 \text{ inches}$ 4th reading depth

Depth of Traverse Readings



If measuring from top, add top plate thickness (usually 3/8 inch)

Total Depth 10 3/8 Inch

Mark the insertion depths on your Pitot tube or use the scale on the side of the Pitot tube


Check Equipment

- Pitot tube
 - Proper length
 - Tip free of nicks and burrs
 - All airways free
 - Blow air through each port section
- Magnehelic Gauge
 - Proper range (Usually a 2" or 4" mag.)
 - Zeroed properly in position of use
 - Orientated properly (vertical or horizontal)

Properly Connect Pitot Tube to Magnehelic Gauge

Measuring Velocity Pressure

Velocity Pressure is "ALWAYS POSITIVE"



If Magnehelic measurement reads below zero, switch any two hose on either side around



Velocity Pressure Readings


- Energize the scrubber and machine water sprays
- Take velocity pressure readings
 - Take readings in the center of each quadrant
 - Best to have one person taking readings while someone else records observed velocity pressures
 - Hold Pitot tube perpendicular to air flow
 - Tip of tube should point directly into direction of airflow
 - Slightly rotate the Pitot tube to obtain highest reading
 - Keep checking to assure all ports remain open
 - Water, dirt and dust can clog the openings
 - If readings vary substantially from previous readings, do not change or become abnormally calm, check the ports
- Take a centerline reading if you wish to use it to establish a Centerline Correlation Factor (CF)

Calculate Scrubber Duct Area

Area of a rectangle duct is length x width

$$A = L \times W$$

- Inside of scrubber measurement: 24 in. x 16 in.



$$\text{Area} = 24/12\text{ft.} \times 16/12\text{ft.} = 2\text{ft} \times 1.33\text{ft} = 2.67 \text{ ft}^2$$

or

$$\text{Area} = 24\text{in.} \times 16\text{in.} / 144 = 2.67 \text{ ft}^2$$

Example of Air Velocity Readings

Duct Cross Sectional Area = 24 in (W) x 16 in (H) = 384 in²
384 in² / 144 in²/ft² = 2.67 ft²

Measurements of VP (inches w.g.)

Ports:	#1	#2	#3	#4	#5	Depth (in.)
	0.9	0.8	1.0	1.0	0.4	2
	0.6	1.1	1.1	0.9	0.4	6
	0.7	1.1	1.5	0.7	0.6	10
	1.0	1.5	1.0	0.5	0.0	14

Centerline Reading (VP) = 1.2" w.g. (Measured in #3 Port at a depth of 8 inches)

Velocity Pressures Converted to Velocities

Velocities (V) (*fpm*)

#1	#2	#3	#4	#5	Sum
3799	3582	4005	4005	2533	17924
3102	4200	4200	3799	2533	17834
3351	4200	4905	3351	3102	18909
4005	4905	4005	2832	0	15747
Total Sum of Velocities:					70,414

Avg. V ($70,414 \div 20$) =

3520 fpm

Centerline V ($1.2w.g$) =

4390 fpm

NOTE: You cannot just average velocity pressures!

Calculate Air Quantity

- Quantity = Area X Avg. Velocity
- $Q = A \times V$
- $Q = 2.67 \text{ ft}^2 \times 3,520 \text{ ft/min} = 9,398 \text{ ft}^3/\text{min}$

Corrections for Elevation or Temperature

- Calculations have been made assuming standard air
 - Standard Air is at
 - Sea Level
 - 70° F
- Corrections are needed if:
 - Elevation varies over 1000 ft.
 - Temperature varies more than 30° F
 - Elevation and temperature affect the density of the air

Corrections for Elevation or Temperature

$$d = \frac{(1.327)(B)}{460 + T}$$

B = barometric pressure, inches of mercury

T = dry bulb temperature of air °F

Correction Chart

		ALTITUDE RELATIVE TO SEA LEVEL, ft																	
		-5000	-4000	-3000	-2000	-1000	0	1000	2000	3000	4000	5000	6000	7000	8000	9000	10000		
		Barometric Pressure																	
T _{Hg}		35.74	34.51	33.31	32.15	31.02	29.92	28.86	27.82	26.82	25.84	24.89	23.98	23.09	22.22	21.39	20.57		
T _w		486.74	469.97	453.67	437.84	422.45	407.50	392.98	378.89	365.21	351.93	339.04	326.54	314.42	302.66	291.26	280.21		
Temp., F	Density Factor, dl																		
	-40	0	40	70	100	150	200	250	300	350	400	450	500	550	600	700	800	900	1000
-40	1.51	1.46	1.40	1.36	1.31	1.26	1.22	1.17	1.13	1.09	1.05	1.01	0.97	0.94	0.90	0.87			
0	1.38	1.33	1.28	1.24	1.19	1.15	1.11	1.07	1.03	1.00	0.96	0.92	0.89	0.86	0.82	0.79			
40	1.27	1.22	1.18	1.14	1.10	1.06	1.02	0.99	0.95	0.92	0.88	0.85	0.82	0.79	0.76	0.73			
70	1.19	1.15	1.11	1.07	1.04	1.00	0.96	0.93	0.90	0.86	0.83	0.80	0.77	0.74	0.71	0.69			
100	1.13	1.09	1.05	1.02	0.98	0.95	0.91	0.88	0.85	0.82	0.79	0.76	0.73	0.70	0.68	0.65			
150	1.04	1.00	0.97	0.93	0.90	0.87	0.84	0.81	0.78	0.75	0.72	0.70	0.67	0.65	0.62	0.60			
200	0.96	0.93	0.89	0.86	0.83	0.80	0.77	0.75	0.72	0.69	0.67	0.64	0.62	0.60	0.57	0.55			
250	0.89	0.86	0.83	0.80	0.77	0.75	0.72	0.69	0.67	0.64	0.62	0.60	0.58	0.55	0.53	0.51			
300	0.83	0.80	0.78	0.75	0.72	0.70	0.67	0.65	0.62	0.60	0.58	0.56	0.54	0.52	0.50	0.48			
350	0.78	0.75	0.73	0.70	0.68	0.65	0.63	0.61	0.59	0.57	0.54	0.52	0.50	0.49	0.47	0.45			
400	0.74	0.71	0.69	0.66	0.64	0.62	0.59	0.57	0.55	0.53	0.51	0.49	0.48	0.46	0.44	0.42			
450	0.70	0.67	0.65	0.63	0.60	0.58	0.56	0.54	0.52	0.50	0.48	0.47	0.45	0.43	0.42	0.40			
500	0.66	0.64	0.61	0.59	0.57	0.55	0.53	0.51	0.49	0.48	0.46	0.44	0.43	0.41	0.39	0.38			
550	0.63	0.61	0.58	0.56	0.54	0.52	0.51	0.49	0.47	0.45	0.44	0.42	0.40	0.39	0.38	0.36			
600	0.60	0.58	0.56	0.54	0.52	0.50	0.48	0.46	0.45	0.43	0.42	0.40	0.39	0.37	0.36	0.34			
700	0.55	0.53	0.51	0.49	0.47	0.46	0.44	0.42	0.41	0.39	0.38	0.37	0.35	0.34	0.33	0.31			
800	0.50	0.49	0.47	0.45	0.44	0.42	0.41	0.39	0.38	0.36	0.35	0.34	0.32	0.31	0.30	0.29			
900	0.47	0.45	0.43	0.42	0.40	0.39	0.38	0.36	0.35	0.34	0.32	0.31	0.30	0.29	0.28	0.27			
1000	0.43	0.42	0.40	0.39	0.38	0.36	0.35	0.34	0.33	0.31	0.30	0.29	0.28	0.27	0.26	0.25			

Correlation Factor

- Correlation Factor is used to relate a centerline air velocity to the **Average Air Velocity** to determine scrubber quantity
- Enables the operator to take only a centerline air velocity reading instead of a full Pitot tube traverse to determine **Average Air Velocity**
- Full Pitot tube traverse required to determine **Average Air Velocity** – normally once per week (if stipulated in your mine ventilation plan)

Correlation Factor

From Previous Example:

Average Velocity from samples was 3520 fpm

Velocity from centerline reading was 4390 fpm

$$\frac{\text{Average Velocity}}{\text{Centerline Velocity}} = \frac{3520 \text{ fpm}}{4390 \text{ fpm}} = .80$$

$$\text{Correlation Factor (CF)} = .80$$

Scrubber Flow Rate

After establishing the Correlation Factor (CF), you can determine the scrubber flow rate using only the centerline air reading, as illustrated in the following example:

Example

Suppose an inspector took a centerline reading as part of the 2nd plan parameter check and recorded the observed velocity pressure as 1.0" w.g.

1. Convert the centerline reading of 1.0" w.g. to a velocity (V), which is 4005 fpm.
2. Multiply the centerline V by the CF to obtain the approximate Avg. V

$$4005 \text{ fpm} \times .80 = 3200 \text{ fpm}$$

3. Multiply the approximate Avg. V by the cross sectional area to obtain the scrubber volume

$$3200 \text{ fpm} \times 2.67 \text{ ft}^2 = 8544 \text{ cfm}$$

Example (continued)

- Now, compare the quantity of 8544 cfm obtained using a centerline air reading to 9398 cfm, the quantity based on full Pitot traverse readings:

$$\frac{8544 \text{ cfm}}{9398 \text{ cfm}} = .91 = 91 \%$$

This scrubber is producing 91 percent of its full traverse air quantity!

What if the scrubber has an even number of test ports?

- A centerline reading must be taken in the middle 2 ports
- These 2 readings are then converted into velocity readings
- The two readings are averaged
- This average reading is related to the average air velocity based on full Pitot traverse readings to obtain the Correlation Factor (CF)
- Two centerline readings used to establish the CF must be obtained when the full Pitot traverse readings are taken

Questions?

- Mark Schultz, P.E.
- 412 386 6807
- schultz.mark.j@dol.gov